




The Service Side of Sears.™

REPAIR PARTS LIST

253.71055010

**To Call Toll Free
For Parts:
1-800-366-PART
(1-800-366-7278)**

**For Service:
1-800-4-MY-HOMETM
(1-800-469-4663)**



AIR CONDITIONER

In all orders or correspondence avoid delays and misunderstandings by always giving the complete model number.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Service Center, or the Service Department at most Sears stores. To order parts by phone, call the toll free part number listed to the left.

When requesting service or ordering parts, always provide the following information:

Product Type

Part Number


Model Number

Part Description

Sears, Roebuck and Co., Hoffman Estates, IL 60179, U.S.A

F/N 01RPR-D28

CABINET FRONT AND WRAPPER




CABINET FRONT AND WRAPPER

| POS. NO. | PART NO. | DESCRIPTION |
|-----------------|-----------------|-------------------------------|
| 1 | 5304413783 | Cabinet |
| 7 | 309638001 | Link / handle |
| 8 | 309637901 | Louver-horizontal |
| 9 | 309342001 | Louver, Vertical, (6) |
| 12 | 309638102 | Filter-Molded |
| 17 | 309640103 | Front, cabinet, complete |
| 19 | 309340801 | Overlay-Electronic control |
| 25 | 309328601 | Door-Vent Actuator |
| 26 | 309638201 | Handle-Vent Barcelona SCTSDL |
| 26A* | 309330201 | Vent-Detent |
| 38 | 309637801 | Panel-front |
| 43 | 309637701 | Frame- front |
| 70 | 309340301 | Enclosure |
| 78 | 309342603 | Remote Control |
| | | |
| * | 309640201 | Louver assy-includes 7, 8 & 9 |
| | | |
| * | 309001275 | Sheet-Tech Data 71055010 |
| * | 309000829 | Owners Manual |

= Functional Parts
 * = Non-illustrated Parts

CONTROL PARTS




CONTROL PARTS

| POS. NO. | PART NO. | DESCRIPTION |
|----------|------------|----------------------------------|
| 7 | 309340402 | Box-Control |
| 10 | 309602403 | Bulkhead |
| 12 * | 5304413782 | Clip-thermister holder |
| 13# | 5304413779 | Capacitor, 370V, 35+4 mfd |
| 14 | 5303303691 | Screw, truss head, 8-18AB x 0.38 |
| 15 | 5303303086 | Strap-capacitor |
| 17# | 309343101 | Cord-power 115v |
| 19 | 5303302855 | Cover, capacitor |
| 70 # | 309340301 | Enclosure |
| 71 # | 309350401 | Power board |
| 72 # | 309350402 | Input board |
| 74 | 5303301590 | Screw, (2) |
| 75 | 5304413781 | Hardware, (4) |
| 76 # | 309111601 | Transformer |

= Functional Parts
 * = Non-illustrated Parts

AIR HANDLING PARTS




P40M0005

AIR HANDLING PARTS

| POS. NO. | PART NO. | DESCRIPTION |
|----------|--------------|-------------------------------------|
| 1# | 309624506 | Fan Blade, with clamp |
| 2 | 08007481 | Nut-motor mounting |
| 3 | 309624201 | Housing-fan |
| 4 | 5303270043 | Seal, condenser |
| 8# | 309645001 | Motor-Fan WELLING 3SP |
| 10 | 309602403 | Bulkhead |
| 11 | 309631702 | Blower Wheel |
| 12 | 327161302 | Clamp-blower |
| 15 | 5304407653 | Housing-blower |
| 16 | 309100201 | Clip |
| 17 | 5308011040 | Clamp (part of fan blade assy) |
| 18 | Not Separate | Deflector-housing (part of housing) |
| 20 | 5304407654 | Plate-Scroll |

= Functional Parts
 * = Non-illustrated Parts

COMPRESSOR PARTS


P40C0056

COMPRESSOR PARTS

| POS. NO. | PART NO. | DESCRIPTION |
|----------|------------|------------------------------|
| 1# | 5304417319 | Compressor |
| 2 | 5303283877 | Grommet-compressor,3 |
| 3 | 5308006948 | Nut, compressor, 3 |
| 6 | 5303291330 | Gasket-cover |
| 7 | 5303291329 | Cover,terminal |
| 8# | 5304417320 | Overload protector |
| 9 | 5303294292 | Nut, cover |
| 10 | 5303317601 | Start Assist Kit, compressor |
| 11# | 309604221 | Evap-Assy |
| 12# | 5303307226 | Condenser |
| 13 | 5303302849 | Tray-Evap |
| 14 | 5304413780 | Base/Compressor-Stud Assy |
| 16# | 5308017120 | Capillary Tube |
| 17 | 5304413857 | Drier-filter |
| 19 | 5303002664 | Washer,compressor |
| 20 | 5303291328 | Spring-overload |
| 21 | 5303293809 | Washer, cover |

= Functional Parts
 * = Non-illustrated Parts

WINDOW MOUNTING PARTS



P40A0008

| POS. NO. | PART NO. | DESCRIPTION |
|----------|------------|-------------------------------|
| 1 | 5304407729 | Seal, frame, top |
| 2 | 5303211056 | Bracket |
| 4 | 5304413847 | Frame,LH |
| 5 | 0806226 | Seal-top rail |
| 6 | Not Used | Retainers are part of cabinet |
| 14 | 5304413848 | Frame,RH |
| 15 | 309626504 | Accordion |
| 16 | 5304413784 | Rail,top |
| 17 | 3002803 | Screw-wood |
| 18 | 5303303691 | Screw, 8-18AB x .38 |
| 20 | 5303295750 | Screw, 8-18 x .75 |
| 22 | 5304403252 | Retainer, bottom |
| 23 | 3001806 | Screw |
| 24 | 530802974 | Screw |


= Functional Parts
 * = Non-illustrated Parts

WIRING DIAGRAM

309341601

SUB.

1



Get it fixed, at your home or ours!

For repair of major brand appliances **in your own home...**
no matter who made it, no matter who sold it!

1-800-4-MY-HOMESM Anytime, day or night
(1-800-469-4663)

www.sears.com

To bring in products such as vacuums, lawn equipment and electronics
for repair, call for the location of your nearest **Sears Parts & Repair Center.**

1-800-488-1222 Anytime, day or night

www.sears.com

For the replacement parts, accessories and owner's manuals
that you need to do-it-yourself, call **Sears PartsDirectSM!**

1-800-366-PART 6 a.m. – 11 p.m. CST,
(1-800-366-7278) 7 days a week

www.sears.com/partsdirect

To purchase or inquire about a Sears Service Agreement:

1-800-827-6655

7 a.m. – 5 p.m. CST, Mon. – Sat.

Para pedir servicio de reparación a domicilio,
y para ordenar piezas con entrega a domicilio:

1-888-SU-HOGARSM
(1-888-784-6427)

Au Canada pour service en français:

1-877-LE-FOYERSM
(1-877-533-6937)

SEARS
HomeCentralSM